

ILLUSTRATED PARTS MANUAL



Transmatic Lawn Tractor — Model Series 780

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank You

Thank you for purchasing this lawn tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing.

Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models. Components

listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Axle, Front	10	Hood	4-7
Battery	8	Deck Lift Handle/Linkage	8
Head Lamps	4-7	Muffler	20
Mower Deck, 42-inch	16	PTO Lever	8
Mower Deck, 46-inch	18	Seat	12
Pedal Controls	14	Steering Wheel	10
Dash Panel	4-7	Switches, Interlock	8
Drive System	14	Throttle Control	4-7
Electrical Schematic	22	Transmission	14
Engine Accessories	20	Wheels, Front	10
Fender	12	Wheels, Rear	14
Frame	8	Wiring Harness Schematic	22
Fuel Tank	4-7		

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------

SERIAL NUMBER

-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------	-------------


Painted Parts

When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXXX-0637). Please refer to the table below for current color codes:

0637	Black	0674	Yellow (Yard-Man)
0709	Dark Green (Bolens, Yard-Man)	0650	Metallic Red (White Outdoor)
0662	Oyster Gray (MTD Gold)	0629	Silver Flake (MTD Platinum)
0638	Red (Yard Machines, Huskee, Troy-Bilt, MTD)	04038	Day Orange (Daedong)
0691	Black Jack (MTD Gold, MasterCut)	04033	Flint Mica (Troy-Bilt XP)

[illegible]


K Style Hood



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	631-04272	Grill Assembly, Troy-Bilt	30	783-04903A	Speed Latch - No RMC
2	731-06404	K-Style Bumper	31	683-04448	Battery Assembly Rod
3	683-04441	Hood Assembly	32	726-0230	Cable Tie
4	710-04484	Screw, 5/16-18 x .750	33	751-0555B	1.5 Gallon Fuel Tank
5	710-0895	Screw, 1/4-15 x .750	34	751-0603A	Fuel Cap
6	725-0157	Cable Tie	35	951-04304	1.36 Gallon Fuel Tank
7	925-0963	Lamp	36	925-1745A	Key
8	731-06095	Left Lens	37	725-0157	Cable Tie
9	731-06096	Right Lens	38	936-3008	Flat Washer, .344 x .750 x .120
10	738-04091A	Shoulder Screw, 5/16-18 x .43 x .29	39	951-10589	5 Gallon Carbon Canister
11	783-05327B	Left Support Pivot Bracket	40	951-10590	Vent Filter Canister
12	783-05328A	Right Support Pivot Bracket	41	951-10610	Canister Adapter Bracket
13	710-04483	Screw, 1/4-20 x .500	42	751-10749-30	Fuel Hose, White
14	710-05070	Screw, 1/4-20 x .500	43	751-10750-28	Fuel Hose, Yellow
15	710-0604A	Screw, 5/16-18 x .625	44	925-04659	3 Position Key Switch
16	712-04063	Flangelock Nut, 5/16-18	45	951-10947	Fuel Cap, 2.25"
17	710-05281	Screw, #12-16 x 1.25		951-12179	Fuel Cap, 2.25" EPA
18	783-04584B	Gas Tank Support Bracket	46	751-12118	Rollover Valve
19	910-0224	Screw, #10-16 x .500	47	735-04081	Rubber Grommet, 23 x 3.55
20	731-05265	Choke Plug	48	751-12089-28	Hose Vent, 3/16 EPA
21	710-0599	Hex Washer Screw, 1/4-20 x .500	49	710-0778	Hex Washer Screw, 1/4-20 x 1.50
22	710-3144	Hex Screw, 3/8-16 x 2.0	50	712-04065	Flangelock Nut, 3/8-16
23	710-3025	Hex Screw, 5/16-18 x .625	51	731-07885	Shift Lever
24	931-08054	Dash, Upper	52	731-07966	Index Control
25	741-0587	Bearing, .628 ID x 1.36	53	732-04800	Compression Spring, .72 OD x .78
26	783-06785	Bracket, Steering Support	54	736-3006	Lock Washer, 1/4
27	783-06811	Dash, Lower	55	747-05398	Speed Control Rod
28	750-04465B	Flange Spacer, .390 x .671 x 1.095	56	783-06823	Speed Latch Tab
29	746-04364	Throttle/Choke Cable			

NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.


5 Style Hood



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	710-05070	Screw, 1/4-20 x .500	23	731-04949A	Grill Lens
2	710-0599	Hex Index Washer Screw, 1/4-20 x .500	24	731-05078C	Dash
3	710-0604A	Screw, 5/16-18 x .625	25	751-12089-28	Hose Vent, 3/16 EPA
4	710-05108	Screw, 1/4-15 x .750	26	738-04091A	Shoulder Screw, 5/16-18, .43 x .29
5	712-04063	Flangelock Nut, 5/16-18	27	783-05327B	Left-hand Support Pivot Bracket
6	731-04945	Steering Support	28	783-05328A	Right-hand Support Pivot Bracket
7	783-04584B	Gas Tank Support Bracket	29	783-05454	Hood Pivot Bracket
8	783-04873B	Dash, No RMC	30	783-05683	Hood
9	983-04226	Speed Control Assembly	31	783-05685	Grill
10	710-3144	Hex Screw, 3/8-16 x 2.0	32	783-04903	Speed Latch, No RMC
11	711-0736	Ferrule, 1/4-20 x 1.0	33	925-04659	Key Switch
12	712-04065	Flangelock Nut, 3/8-16	34	925-1745A	Key
13	714-04040	Bow Tie Cotter Pin, 72	35	731-05265	Choke Plug
14	783-06823	Speed Latch Tab	36	683-04448	Battery Rod
15	747-04430	Speed Selector Control Rod	37	726-0230	Cable Tie
16	750-04465B	Flange Spacer, .390 x .671 x 1.095	38	751-0555B	Fuel Tank, 1.5 Gallon
17	710-04484	Screw, 5/16-18 x .750		951-04304	1.36 Gallon Fuel Tank EPA
18	710-04593	Screw, 5/16-18 x .375	39	751-0603A	Fuel Cap
19	710-0751	Hex Screw, 1/4-20 x .620		951-12179	Fuel Cap, 2.25" EPA
20	712-04064	Flangelock Nut, 1/4-20	40	746-04364	Throttle/Choke Cable
21	725-0157	Cable Tie	41	735-04081	Rubber Grommet, 23 x 3.55
22	925-0963	Miniature Lamp, 12V	42	751-12118	Rollover Valve

NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.


Frame and PTO Lift



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	683-04195	Support Bracket	30	747-04282	Deck Lift Handle
2	683-04649	Frame Assembly	31	747-04393	Lift Rod
3	710-0134	Screw Carriage, 1/4-20 x .62	32	783-04494C	42" Lift Arm, RH
4	710-04484	Screw 5/16-18 x .750	33	783-04711C	42" Lift Arm, LH
5	710-0599	Screw, 1/4-20 x .500	34	725-04363	Switch Interlock
6	710-3008	Hex Screw, 5/16-18 x .75	35	683-04334	Lift Assembly, 46"
7	712-04063	Flangelock Nut, 5/16-18	36	710-0604A	Screw, 5/16-18 x .625
8	712-04064	Flangelock Nut, 1/4-20	37	720-0298	Handle Grip, 5/8
9	912-0429	Hexlock Nut, 5/16-18	38	732-04438	Torsion Spring Handle, 46"
10	732-04035	Compression Spacer, 1.28 x 3.125	39	936-0140	Flat Washer, .385 x .62 x .063
11	736-0173	Flat Washer, .28 x .74 x .063	40	938-0380	Shoulder Bolt, 3/8-16 x .500 x .270
12	738-04237A	Shoulder Spacer, 10-32 x .500	41	747-04653	46" Lift Handle
13	783-04548D	Seat Frame Bracket	42	783-05389	Frame Brace Bracket
14	783-04637	Running Board Bracket	43	783-0678C	Lift Deck Link
15	783-04753	Support Frame Bracket	44	710-04608	Hex Screw, 7/16-20 x 3.25
16	783-04869A	Battery Bracket	45	914-0145	Click Pin, .092 x 1.64
17	710-04666	Hex Head Flange, 1/4-20 x .75	46	720-04049A	Handle Grip, 3/8
18	712-0271	Sems Nut, 1/4-20	47	732-04276A	PTO Spring Extension
19	925-1707D	230 CCA Battery	48	936-0171	Regular Duty Washer Lock, 7/16
20	783-04536B	Support Bracket	49	736-0322	Flat Washer, .450 x 1.250 x .164
21	647-04096	PTO Handle Assembly	50	741-04119A	PTO Bearing
22	683-04155A	Lift Assembly, 42"	51	946-04173C	Deck Engage Cable
23	712-04065	Flangelock Nut, 3/8-16	52	756-04196A	Engine Pulley, 3.39 x 6.12
24	714-04040	Bow-tie Cotter Pin	53	683-04448	Battery Hold Down Rod
25	716-0106A	E Ring	54	936-0300	Flat Washer, .406 x .875 x .059
26	720-0311	Handle Grip, 1/2	55	747-04857	42" Belt Keeper
27	732-04225	Torsion Spring		683-04414	46" Belt Keeper
28	738-04130	Shoulder Bolt, 3/8-16 x .625 x .175	56	710-0604A	Screw, 5/16-18.0 x .625
29	941-0225	Hex Flange Bearing	57	725-04439	12V Solenoid

NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

Front End Steering




Front End Steering

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	617-04094	Front Steering Gear Assembly	25	634-04086	Wheel Assembly, 42"
2	710-0514	Hex Screw, 3/8-16 x 1.00		634-04639	Wheel Assembly, 46"
3	710-0643	Hex Screw, 5/16-18 x 1.00, Lock	26	710-04484	Screw, 5/16-18 x .750
4	710-1309	Machine Screw, 5/16-18 x .750	27	712-04065	Flangelock Nut, 3/8-16
5	710-3180	Hex Screw, 5/16-18 x 1.75	28	914-0474	Cotter Pin, .125 x .75
6	912-0240	Jam Nut, 7/16-20	29	919-04177A	Pivot Axle
7	912-0214	Jamlock Nut, 3/8-24	30	726-04035	Push Nut, 3/4
8	712-04063	Flangelock Nut, 5/16-18	31	731-04693	Hub Cap
9	938-04013	42" & 46" Front RH Axle	32	936-0316	Flat Washer, .78 x 1.59 x .060
10	923-0448A	Ball Joint, 7/16-20	33	748-04068	Spacer, .71 x .125 x .56
11	736-0242	Bell Washer, .340 x .872 x .060	34	738-04128	Shoulder Bolt, 3/8-16 x .500 x 2.38
12	938-04014A	42" & 46" Front LH Axle	35	747-04299A	Fixed Rod
13	738-04141	Shoulder Bolt, 5/16-18 x .435 x .350	36	783-05326B	Pivot Bar Bracket
14	738-0919A	Steering Shaft, 5/8 x 22.08	37	726-0341	Push Cap, 3/4
15	941-04124	Flange Bearing, 5/8	38	731-04057A	Standard Axle Cap
16	934-0255	Valve, tubeless Air	39	741-0660A	Flange Bearing, .760 x .941 x 1.0
17	747-05385	Steering Link	40	631-04028	Steering Wheel
18	948-0389	Cap, 1.25 x .16		631-04560	Steering Wheel Soft Grip
19	748-04065	Steering Block	41	931-0484A	Hub Cap
20	748-04068	Spacer, .71 x .125 x .56	42	731-04040	Sprig Cap
21	734-1731	Tire, 15 X 6 X 6 Sq Shoulder		731-04681	Cap, Troy-Bilt
22	738-04162A	Shoulder Spacer, .884 x .190	43	783-04568	Front Deck Hanger Bracket
23	736-04228A	Flat Washer, .781 x 1.590	44	934-04081	Rim Asm, 6.0x4.5, 42" Deck
24	714-04039A	Cotter Pin, 5/32 x 1.25		634-04634	Rim Asm, 6.0x4.5, 46" Deck

NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.


Seat and Fender



Ref. No.	Part No.	Description
1	710-05070	Screw, 1/4-20 x .500
2	710-04484	Screw, 5/16-18 x .750
3	710-0599	Screw Pan Torx Head, 1/4-20 x .500
4	731-04591A	Cup Holder
5	710-0134	Screw Carriage, 1/4-20 x .62
6	783-04587D	Fender - Red
7	783-04843	Lift Adjuster Bracket - Powder Black
8	783-1489D	Seat Mount Bracket - Powder Black
9	712-04063	Flangelock Nut, 5/16-18
10	732-1184	Extension Spring
11	936-0108	Flat Washer, .510x .750 x .033
12	736-0242	Bell Washer, .340 x .872 x .060
13	938-0296	Shoulder Screw, 5/16-18 x .437 x .268
14	783-0209D	Lift Seat Bracket
15	783-04081C	Pivot Seat Manual Adjust Bracket
16	710-04482	Hex Head Flange, 3/8-16 x .875
17	725-1439	Inner Seat Spring
18	720-04061	Knob, 3/8-16 x .875
19	735-04047	Foot Pad, LH
	723-04026	Foot Pad, Abrasive, LH
20	735-04048	Foot Pad, RH
	723-04025	Foot Pad, Abrasive, RH
21	726-3046	Ratchet Clip, .250 x .500
22	710-0227	Screw, 8-18 x .500
23	726-0279	Insulator Plate
24	925-1303	Outer Seat Spring
25	726-0278	Insulator Boss Plate
26	757-04083	Med. Back Seat, Black, Set-up B or C


NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

Transmission



Ref.	Part No.	Description	Ref.	Part No.	Description
1	918-04566	Dr Asm, autodrive Lt-5	46	725-04363	Switch Interlock
2	17962	Plate Switch	47	736-0242	Bell Washer, .340 x .872 x .060
3	647-04035	Lvr Asm, shft	48	738-0372B	Spcr, shldr, 1.00 X .38 X .38
4	647-04201	Ped Asm, drive, autodrive Lt-5	49	738-04091A	Scr, shldr, .43x.29, Tt, 5/16-18
5	647-04203A	Ped Asm, cont, autodrive Lt-5	50	783-06807	Plate, Stop Pedal
6	683-04607	Brkt Asm, pedal, autodrive	51	741-0495	Brg, flg, .630 Idx .695 Od X .60
7	710-0227	Scr, ab, #8-18, 0.500, Hxindwsh	52	741-3065B	Brg, hex Flg, .628 Id, split
8	710-04484	Scr, tt, 5/16-18, .750, Hxindwsh	53	747-05188	Rod, brake, lt-5 Trans
9	710-0604A	Scr, tt, 5/16-18, 0.625, Hxindwsh	54	747-05243	Rod, shift, lt-5 Stretch 46"
10	710-0809	Scr, tt, 1/4-20, 1.250, Hxindwsh	55	747-05251A	Rod, adj, idlr, 3/8
11	710-0859	Hhcs, 3/8-16, 2.50, Gr5, Std	56	747-05415	Rod, trans, footpedal Bypass
12	710-1007	Scr, ttsems, 3/8-16, 1.500, Hxlvsh	57	948-0334	Spcr, T-Axle .68
13	710-1858A	Scr, tt, 3/8-16, 1.750, hxindwsh	58	750-04456	Spcr, .260 X .372 X 1.420 Lg
14	710-1266	Hhcs, 5/16-18, 3.50, Gr5, Std	59	750-0566A	Spcr, .260 X .375 X 1.030 Lg
15	710-1325	Scr, tt, 1/4-20, 1.625, Hxindwsh	60	954-04208	Belt, v Typ, 5l X 40.9 Lg Poly
16	710-3008	Hhcs, 5/16-18, .75, Gr5, Std	61	954-0467A	Belt, v Typ, 5l, 90.93, Poly
17	912-0240	Nut, jam, 7/16-20, Gr2	62	956-04002	Pul, v Typ, 7.25 Dia Spun
18	712-0241	Nut, hex, 3/8-24, Gr5	63	756-04224	Pul, idlr, flat 2.75 Od
19	712-04063	Nut, flglk, 5/16-18, Grf, nylon	64	756-04325	Pul, idlr, v-Type X 3.06
20	732-04764	Spr, extn, .56 x 12.05 x .068	65	783-04536B	Brkt, ped, support Lt-5
21	912-3000	Nut, hexlck, 3/8-16, cntrlck	66	783-04595A	Brkt, shft, adj
22	712-0700	Nut, flg, 9/16-18, Gr2	67	783-06278	Plt, brkt, reinforcement
23	914-0111	Pin, cot, 3/32, 1.0	68	783-06562A	Brkt, ped, frame Rh
24	914-0209	Pin, cotter Int- .125 Dia	69	783-06769	Brkt, idlr, center Dbl
25	714-04040	Pin, cot, bow-Tie 72	70	783-06592A	Brkt, idlr, dbl Autodrive Lt-5
26	718-04407	Hub, pul, 5/8 Spline	71	783-06641	Brkt, supt, pedal Stap
27	720-04028	Knob, shft	72	683-04521	Brkt Asm, idlr
28	923-3018	Ball, joint	73	683-04606	Brkt Asm, autodrive Lt-5
29	725-0157	Cbl, tie, 3/16 X .05 X 7.4	74	710-1260A	Scr, tt, 5/16-18, 0.750, Hxindwsh
30	725-1644	Sw, spr, short	75	710-3005	Hhcs, 3/8-16, 1.25, Gr5, Std
31	726-0214	Cap, push 5/8	76	712-04065	Nut, flglk, 3/8-16, Grf, nylon
32	926-0320	Plate, Insulator Nut	77	738-04162A	Spcr, shldr, .8840 X .190
33	731-04602	Slev, .758 X .821 X 3.3125	78	956-04015A	Pul Asm, var Spd, 4.75 Od
34	731-04604	Slev, .758 X .821 X 2.4375	79	683-04522	Keepr Asm, belt
35	731-06330	Plug, deck Hole, 7/8	80	683-04612	Brkt Asm, vari Painted
36	731-06894	Brg, plt;Shift	81	710-0627	Hhcs, 5/16-24, .750, Gr5, Lock
37	732-04488	Spr, ext, .38 Od X 3.25 Lg	82	710-0778	Scr, tt, 1/4-20, 1.500, Hxindwsh
38	732-04612	Spr, extn, .70 Dia X 12.00 Lg	83	718-04261	Cup, brg
39	732-04616B	Spr, extn, .97 Od X 6.18 Lg	84	736-0362	Wash, flat, .330 X 1.25 X .06, Ht
40	732-0716D	Spr, extn, .59 Od X 4.00 Lg	85	941-0600	Brg, ball, 17x40x12, 6203, Ds
41	735-0239	Pad, foot, 4.0 Long	86	634-0104	Wheel, 20 x 8 x 8
42	735-0662	Pad, cont	87	634-04369	Rim Asm:8.0 X 7.0 X .750 Id
43	936-0169	Wash, lock, 3/8, Regular Duty	88	934-0255	Valve, tubeless Air
44	736-3040	Wash, Flat, .406 x 1.920 x .060	89	734-1730	Tire, 20 X 8 X 8 Sq Sh
45	936-0185	Wash, flat, .375 X .738 X .063			


NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.



Ref.	Part Number	Description	Ref.	Part Number	Description
1.	918-04822A	Spdl Asm, Pul, 6.3 Dia	31.	736-0225	Wash, Lock, 5/8, Int Tooth
2.	683-0254B	Brkt Asm, Deck, Hngr Lh Lt	32.	736-0262	Wash, Flat, .385 X .870 X .092
3.	983-04511	Brake Asm, Deck, 42/46	33.	750-04936	Spcr, .792 X 1.060 X 1.860 Lg
4.	983-04525	Brake Asm, Deck, 46"	34.	736-0362	Wash, Flat, .330 X 1.25 X .06, Ht
5.	983-04572	Deck Asm, Sd, Offset, 42 W/ 2whl	35.	738-04146	Plug, Bolt, M16 X 1.5
6.	710-04484	Scr, Tt, 5/16-18, .750, Hxindwsh	36.	738-04162A	Spcr, Shldr, .8840 X .190
7.	710-0514	Hhcs, 3/8-16, 1.00, Gr5, Std	37.	748-0234	Shoulder Spacer
8.	710-0528	Hhcs, 5/16-18, 1.25, Gr5, Std	38.	938-3056	Bolt, Shldr, .496 X 2.50, 3/8-16
9.	710-0599	Scr, Tt, 1/4-20, 0.500, Hxindwsh	39.	942-04308	Blade, Cut, 21.23" 2-In-1, Econ
10.	710-0778	Scr, Tt, 1/4-20, 1.500, Hxindwsh	40.	747-05323	Rod, Keepr, Belt 42 Idler
11.	710-0642	Scr, Tt, 1/4-20, .750, Hxindwsh	41.	747-05141A	Rod, Lift, Deck, Frt, 12.7
12.	710-3144	Hhcs, 3/8-16, 2.00, Gr5, Std	42.	747-05105	Rod, Cont, Brake 42"
13.	710-3178	Bolt, Crg, 3/8-16, 0.75, Gr1	43.	631-04288	Chut Asm, 42" Deck, Exp
14.	712-0229	Nut, Push, 3/8	44.	737-04003D	Deck Water Nozzle
15.	712-04063	Nut, Flglk, 5/16-18, Grf, Nylon	45.	750-0258	Spcr, .315 X .750 X .375 Lg
16.	712-04065	Nut, Flglk, 3/8-16, Grf, Nylon	46.	750-0566A	Spcr, .260 X .375 X 1.030 Lg
17.	712-0417A	Nut, Flg, 5/8-18	47.	954-04060B	Belt, V Typ, A Sec X 96.5
18.	712-04243	Nut, Flxlk, 1/2-13	48.	756-04129B	Pul, Idlr, 4.25"Dia
19.	912-0641	Nut, Hex, M16-1.5 Din 936	49.	711-04847B	Pin, Hinge, Dia .3125 X 7.96 Lg
20.	714-04043	Bow-Tie Cotter Pin	50.	956-1227	Pul, Deck, 6.3 Dia
21.	783-06074A	Chute Bracket	51.	732-04372	Spr, Torsion, .44 I.D. X 2.0
22.	917-04074	Gear, Deck, Adj	52.	783-05946	Brkt, Idlr, Piv, 46
23.	932-0384	Spr, Extn, .62 Dia X 6.12 Lg	53.	783-06243	Brkt, Cbl, Deck Engage
24.	921-04041	Water Nozzle Adapter	54.	783-06368A	Brkt, Guard, Belt, 4.25 Pulley
25.	732-04727	Spr, Torsn, .992 I.D X 1.17 O.D	55.	783-06424A	Cvr, Belt, Deck, 42
26.	734-04155	Whl, Deck, 5.0 Dia Ball	56.	748-04069	Deck Lift Pivot Cup
27.	936-0119	Wash, Lock, 5/16, Regular Duty	57.	783-06643	Brkt, Supt, Deck Stationary Idlr
28.	941-0919	Brg, Ball, .787id X 1.85 Odx.551	58.	712-0417A	Nut, Flg, 5/8-18
29.	936-0344	Wash, Flat, .385 X 1.0 X .030	59.	936-0351	Wash, Flat, .760 Idx1.50 Od
30.	736-0187	Wash, Flat, .64 X 1.24 X .06, Ht	60.	738-1186A	Shft, Spdl, 6.11 Lg.


NOTE, Tractor features vary by model. NOT all parts listed above and pictured on the previous page are standard equipment.

46" Deck




Ref.	Part Number	Description
1.	918-04865A	Spdl Asm, Pul 6.93 Dia W/O Zerk
2.	683-0254B	Brkt Asm, Deck, Hngr Lh Lt
3.	631-04288	Chute Deflector Assembly
4.	983-04511	Brake Asm, Deck, 42/46
5.	983-04525	Brake Asm, Deck, 46"
6.	983-04704	Deck Asm, 46t, 2w
7.	710-0347	Hhcs, 3/8-16, 1.75, Gr5, Std
8.	710-04484	Scr, Tt, 5/16-18, .750, Hxindwsh
9.	710-0514	Hhcs, 3/8-16, 1.00, Gr5, Std
10.	710-0528	Hhcs, 5/16-18, 1.25, Gr5, Std
11.	710-0599	Scr, Tt, 1/4-20, 0.500, Hxindwsh
12.	710-0642	Scr, Tt, 1/4-20, 0.750, Hxindwsh
13.	710-0778	Scr, Tt, 1/4-20, 1.500, Hxindwsh
14.	710-1003	Scr, B, #10-16, 0.625, Hxindwsh, Sp
15.	710-3005	Hhcs, 3/8-16, 1.25, Gr5, Std
16.	710-3178	Bolt, Crg, 3/8-16, 0.75, Gr1
17.	712-0229	Nut, Push, 3/8
18.	712-04063	Nut, Flglk, 5/16-18, Grf, Nylon
19.	712-04065	Nut, Flglk, 3/8-16, Grf, Nylon
20.	712-0417A	Nut, Flg, 5/8-18
21.	712-04243	Nut, Flxlk, 1/2-13
22.	912-0641	Nut, Hex, M16-1.5 Din 936
23.	714-04043	Pin, Cot, Bow-Tie 91
24.	914-0470	Pin, Cot, Split, 1/8x1.25
25.	917-04074	Gear, Deck, Adj
26.	921-04041	Adap, Water Nozzle
27.	731-06496	Cvr, Belt, Universal
28.	932-0384	Spr, Extn, .62 Dia X 6.12 Lg
29.	732-04652	Spr, Comp, .70 Od X 2.06 Lg
30.	732-04773	Spr, Torsn, .992 I.D X 1.17 O.D
31.	732-04871	Spr, Extn, 1.00 X 7.1175 X .183
32.	734-04155	Whl, Deck, 5.0 Dia Ball
33.	735-0271A	Bmpr, .62 Dia X .3
34.	936-0119	Wash, Lock, 5/16, Splt, Reg

Ref.	Part Number	Description
35.	736-0225	Wash, Lock, 5/8, Int Tooth
36.	736-0262	Wash, Flat, .385x.870x.092
37.	936-0344	Wash, Flat, .385 X 1.0 X .030
38.	736-0362	Wash, Flat, .330x1.250x.060, Hd
39.	736-0371	Wash, Flat, .343 X .880 X .062
40.	737-04003D	Noz, Deck, Water
41.	738-04162A	Spcr, Shldr, .8840 X .190
42.	738-0754	Scr, Shld, .437 Dia. X .54
43.	938-3056	Shld-Scr - 1/2 Dia X 2.50 Lg.
44.	942-04290	Blade, Cut, 23.25" 2-In-1, Econ
45.	747-05011	Rod, Keepr, Belt
46.	747-05052	Rod, Cont, Brake 46"
47.	747-05141A	Rod, Lift, Deck, Medium
48.	747-05323	Rod, Keepr, Belt, 42s 46t
49.	747-1116	Rod, Hndl, Deck Rel .375 Dia
50.	748-0234	Shoulder Spacer
51.	748-04069	Cup, Pivot, Deck Lift
52.	750-0258	Spcr, .315 X .750 X .375 Lg
53.	750-0566A	Spcr, .260 X .372 X 1.030 Lg
54.	751B221535	Clamp, Casing
55.	954-04219	Belt, V Typ, A Sec X 106.62
56.	756-04129B	Pul, Idlr, 4.25"Dia
57.	711-04847B	Hinge Pin
58.	732-04372	Torsion Spring
59.	783-05946	Brkt, Idlr, Piv, 46
60.	783-06243	Brkt, Cbl, Deck Engage
61.	783-06368A	Brkt, Guard, Belt, 4.25 Pulley
62.	783-06981	Brkt, Idlr, 46" Lh
63.	783-06074A	Chute Bracket
64.	756-04356	Deck Pulley, 6.93 DIA
65.	941-0919	Ball Bearing, .787ID X 1.85 ODX.551
66.	750-04936	Spacer, .792 X 1.060 X 1.860 LG
67.	738-1186A	Spindle Shaft, 6.05 LG.



Ref. No.	Part No.	Description
1	683-04549	Muffler Shield Assembly with Weld
2	710-0227	Screw, 8-18 x .500
3	710-04683	Screw, 3/8-16 x 1.0
4	710-0642	Screw, 1/4-20 x .750
5	710-1314A	Socket Screw, 5/16-18 x .750
6	712-0271	Sems Nut, 1/4-20
7	BS-692236	Exhaust Gasket, 10 HP Briggs
8	725-0157	Cable Tie
9	726-0205	Clamp Hose, .490 diameter
10	751-10349-28	Fuel Hose, Low Permeation
11	731-05628	Oil Drain Sleeve
12	751-10448C	Muffler, Single Inlet
13	751-11053	Muffler Deflector Long


NOTE, Tractor features vary by model. NOT all parts listed and pictured above are standard equipment.



Ref. No.	Part No.	Description
1	683-04549	Muffler Shield Assembly with Weld
2	710-0227	Screw, 8-18 x .500
3	710-04683	Screw, 3/8-16 x 1.0
4	710-0599	Screw, 1/4-20 x .500
5	710-0642	Screw, 1/4-20 x .750
6	710-1314A	Socket Screw, 5/16-18 x .750
7	725-0157	Cable Tie
8	726-0205	Clamp Hose, .490 diameter
9	951-10517A	Oil Drain
10	751-3141-14	Oil Drain, Extension Hose
11	751-11943	Muffler
12	751-10349-28	Fuel Hose, Low Permeation
13	751-11053	Muffler Deflector Long

NOTE, Tractor features vary by model. NOT all parts listed and pictured above are standard equipment.

Wiring Harness Schematic - 725-04567F



Notes



To order replacement parts or locate your nearest service dealer call a Customer Support at (800) 800-7310.
or visit www.mtdproducts.com to find the nearest authorized dealer in your area.

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
