




ILLUSTRATED PARTS MANUAL



Hydrostatic Lawn Tractor, 900 Series

TROY-BILT LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019

To The Owner

Thank you for purchasing an MTD Lawn Tractor. It was carefully engineered to provide excellent performance when properly operated and maintained.

All information in this manual is relative to the most recent product information available at the time of printing. Please be aware that this Illustrated Part's Manual may cover a range of product specifications for various models.

Components listed and/or illustrated in this manual may not be applicable to all models. We reserve the right to change product specifications, designs and equipment without notice and without incurring obligation.

Throughout this manual, all references to *right* (RH) and *left* (LH) are observed from the operating position.

Table of Contents

Axle, Front	6	Meter, Systems Indicator	16
Battery	4	Mower Deck, 42-inch	12
Dash Panel	16	Mower Deck, 46-inch	14
Deck Lift Handle/Linkage	8	Muffler	18-19
Drive System	10	Pedal Controls	10
Electrical Schematic, Man. PTO	3	PTO Lever	4
Engine Accessories, Single	18	Seat	8
Engine Accessories, Twin	19	Solenoid	4
Fender	8	Steering Wheel	6
Frame	4	Switches, Interlock	4
Fuel Tank	16	Throttle/Choke Control	16
Head Lamps	16	Wheels, Front	6
Hood	16	Wheels, Rear	10

Record Product Information

To ease in ordering replacement parts, please locate the model plate on the equipment and record the information in the provided area to the right. You can locate the model plate by looking beneath the seat.

MODEL NUMBER

--	--	--	--	--	--	--	--	--	--	--

SERIAL NUMBER


--	--	--	--	--	--	--	--	--	--	--

Painted Parts


When ordering painted service parts, a four digit color suffix must be added to the part number (e.g. 783-XXXX-0637). Please refer to the table below for current color codes:

0637	Black	0650	Metallic Red (White Outdoor)
0709	Dark Green (Bolens, Mastercraft, Yard-Man Domestic)	0665	Dark Green (Yard-Man Export)
0662	Oyster Gray (MTD Gold)	0629	Silver Flake (MTD Platinum)
0638	Red (Yard Machines, Huskee, Troy-Bilt, MTD)	04038	Day Orange (Daedong)
0691	Black Jack (MTD Gold, MasterCut)	04015	Fire Red (Massey Ferguson)
0674	Yellow (Yard-Man)	04033	Flint Mica (Troy-Bilt XP)

Electrical Schematic (Man. PTO)




Manual PTO and Battery



Ref.	Part Number	Description
1	647-04151	Handle Ass'y, PTO
2	710-04379A	Hex Screw, 7/16-20, 3.50, Gr5, Lock
3	710-0599	Screw, Self-tapping, 1/4-20, 0.50
4	714-04040	Pin, Cotter, Bow-Tie 72
5	720-04049A	Grip, Handle, 3/8
6	732-0932	Spring, Ext, .38 Dia x 5.6
7	747-05171A	Belt Keeper Rod
8	736-0322	Washer, Flat, .450 x 1.250 x .164
9	738-04237A	Screw, Shoulder, #10-32, .500
10	741-04119A	Bearing, PTO
11	946-04618B	Cable, Engag, Deck
12	750-0956	Spacer, 1.010 x 1.400 x .825
13	956-04067A	Pulley, Engine, 3.56 x 6.12 Dia.
14	683-04469C	Frame Ass'y, Lower
15	710-04484	Screw, Self-tapping, 5/16-18, .750,
16	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
17	712-04065	Nut, Flange Lock, 3/8-16, Grf,
18	738-04058	Spacer, Shoulder, .38 x 1.0 x .70
19	747-04121A	Rod, Battery
20	783-0349	Tray, Battery
21	783-06089	Bracket, Frame, Seat
22	925-1707D	Battery
23	710-04666	Hex Flange Screw, 1/4-20, .75, Gr5
24	712-0271	Nut, Sems, 1/4-20
25	710-0653	Screw, Self-tapping, 1/4-20, 0.375,
26	712-04064	Nut, Flange Lock, 1/4-20, Grf,
27	725-04232	Switch, 3-Pole
28	725-04363	Switch, Interlock
29	725-04439	Solenoid, 12V
30	725-04807	Switch, Plunger, Snap Mount
—	925-04105	Wire Harness, Main


Steering and Axle



Ref.	Part Number	Description
1	710-04095	Hex Screw, 3/8-16, 1.00, Gr5, Spec
2	710-0514	Hex Screw, 3/8-16, 1.00, Gr5, Std
3	710-0643	Hex Screw, 5/16-18, 1.00, Gr5, Lock
4	711-04998	Link, Drag LH
5	711-04999	Link, Drag RH
6	912-0240	Nut, Jam, 7/16-20, Gr2
7	712-04065	Nut, Flange Lock, 3/8-16, Grf,
8	712-0459	Nut, Flange Lock, 7/16-20, Grb, Lock
9	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
10	717-1550F	Gear, Steering, 11/90 Ratio
11	717-1554	Gear, Pinion, Steering
12	923-0448A	Ball Joint, 7/16-20, Lock
13	936-3004	Washer, Flat, .406 x .875 x .105
14	736-3084	Washer, Flat, .51 x 1.12 x .06
15	938-04034	Axle Ass'y, RH .750 Dia (46" Deck)
—	638-04032	Axle Ass'y, RH .750 Dia (42" Deck)
16	738-04263	Shaft, Steering, .625 OD x 24.25
17	738-04363	Spacer, Shoulder, .385x 1.25 x .3025
18	738-04364B	Spacer, .38 x 1.375, Special, 46" Only
19	741-04237B	Bearing, Flange, Hex 5/8 Pm
20	783-06043	Bracket, Support, Steering
21	710-04484	Screw, Self-tapping, 5/16-18, .750,

Ref.	Part Number	Description
22	710-0395	Hex Screw, 5/16-18, 2.25, Gr5, Std
23	710-0859	Hex Screw, 3/8-16, 2.50, Gr5, Std
24	710-3180	Hex Screw, 5/16-18, 1.75, Gr5, Std
25	912-0214	Nut, Hex Lock, 3/8-24, Grb
26	712-04063	Nut, Flange Lock, 5/16-18, Grf
27	714-0162	Pin, Cotter, 5/32, 1.25
28	719-04413A	Axle, Pivot Bar, Cast
29	748-04278	Steering, Block
30	748-04068	Spacer, .71 ID x .125 OD x .56
31	750-05280	Spacer, .385 x 1.00 x 1.5075
32	631-04008A	Steering Wheel, Soft Grip
33	731-04681	Cap, Troy-Bilt
34	634-04406-0911	Wheel Assembly
35	734-1731-0901	Tire, 15 x 6 x 6
36	634-04405-0662	Rim Assembly, Plastic Bearing
37	934-0255	Tubeless Air Valve
38	741-0516B	Flange Bearing, .760 x 1.00 x 1.20
39	741-0990B	Flange Bearing, .760 ID
40	731-08049	Cap, Bumper
41	736-04228A	Washer, Flat, .350 x 1.559 x .062
42	638-04035P	Axle Ass'y, LH .750 Dia (46" Deck)
—	638-04033	Axle Ass'y, LH .750 Dia (42" Deck)


Seat and Fender



Ref.	Part Number	Description
1	683-04223	Shaft Ass'y, Lift
2	712-04063	Nut, Flange Lock, 5/16-18, Grf
3	712-04065	Nut, Flange Lock, 3/8-16, Grf
4	914-0104	Pin, Cotter, .072 Dia. x 1.13
5	714-04040	Pin, Cotter, Bow-Tie 72, 46"
—	914-0111	Bow-Tie Cotter Pin, 42"
6	716-0106A	Ring, E Type, .625 Dia. Shaft
7	720-0311	Grip, Handle, 1/2
8	732-0874	Spring, Torsion
9	736-0105	Washer, Spring, .401 x .870 x .063
10	738-0138A	Screw, Shoulder, .437 x .470, 5/16-18
11	938-0380	Bolt, Shoulder, .500, 3/8-16, 46"
—	738-04130	Shoulder Bolt, .625 x .175:3/8-16, 42"
12	941-0225	Bearing, Hex Flange
13	746-0968	Cable, Lift, 16.16
14	747-04962A	Handle, Lift,
15	756-04331	Pulley, Roller, Cable
16	783-05546A	Lift Link, 46"
—	783-04494C	Lift Arm, RH, 42"
—	783-04711C	Lift Arm, LH, 42"
17	710-04484	Screw, Self-tapping, 5/16-18, .750,
18	710-1260A	Taptite Screw, 5/16-18:.750
19	710-0599	Screw, Self-tapping, 1/4-20, 0.500,

Ref.	Part Number	Description
20	710-0895	Screw, HL, 1/4-15, 0.750,
21	731-06795	Cover, Lift Lever
22	731-1993A	Cover w/ Cup Holder
23	925-05013	Switch, Seat
24	736-3078	Washer, Flat .344 x 1.00 x .063
25	783-06443	Bracket, Lift, Man PTO, 6 Pos
26	783-06259	Fender
27	712-3004A	Nut, Flange Lock, 5/16-18, Gr5, Sd Lk
28	710-04482	Hex Head Flange, 3/8-16:.875
29	725-0157	Cable, Tie, 3/16 x .05 x 7.4
30	732-04849	Spring, Compr, 1.50 x 3.90 x .200
31	938-0296	Screw, Shoulder, .437 x .268, 5/16-18
32	783-06049	Bracket, Mounting, Seat
33	783-06088	Bracket, Pivot, Seat
34	732-04563	Comp. Spring, .68 x 1.065 x .055
35	783-06448	Clip, Retaining, Switch
36	726-3046	Clip, Ratchet, .250 Dia
37	735-04138	Pad, Foot, LH
38	735-04158	Pad, Foot, RH
39	757-04086	Seat, High Back
—	757-04081	Seat, Med Back, Black
40	783-06050	Seat Adjustment Lever

Drive and Rear Wheels




Drive and Rear Wheels

Ref.	Part Number	Description
1	918-0319	Hydro Transmission
2	710-0176	Hex Screw, 5/16-18:2.75
3	710-0227	Screw, #8-18:0.500
4	710-0351	Screw, #10-16:0.500
5	710-04484	Taptite Screw, 5/16-18:.750
6	710-0653	Taptite Screw, 1/4-20:0.375
7	710-1007	Screw, Sems, 3/8-16, 1.500
8	710-1325	Taptite Screw, 1/4-20:1.625
9	710-3011	Hex Screw, 3/8-16:2.25
10	912-0240	Jam Nut, 7/16-20
11	912-0346	Nut, Jamlock, 1/2-20
12	712-04063	Flangelock Nut, 5/16-18
13	912-0431	Flangelock Nut, 3/8-16
14	914-0111	Cotter Pin, 3/32:1.0
15	725-0157	Cable Tie, 3/16 X .05 X 7.4
16	725-04791A	Jumper Harness
17	725-1644	Short Spring Switch
18	926-0154	Push Mount Cable Tie 7.5 LG
19	926-0320	Insulator Nut Plate
20	731-05299A	Sleeve, .765 ID x 1.500 LG
21	731-06098	Hydro Fan
22	932-0209	Extension Spring, .48 OD X 2.03
23	732-04606	Extension Spring, .500 DIA X 12.6 LG
24	732-04624	Extension Spring, 1.00 DIA X 4.75
25	732-0716D	Extension Spring, .59 OD X 4.00 LG
26	732-0729	Wire Ring
27	732-3118	Extension Spring, .375 OD X 1.44 LG
28	936-0264	Washer, Flat, .330 X .630 X .0635
29	736-04263	Washer, Lock, TRANS HYDRO
30	936-3008	Washer, Flat, .344 X .750 X .120
31	736-3010	Washer, Flat, .407X.812X.135:HT
32	647-04152D	Brake Control Assembly
33	683-04488	Hydro Pedal Bracket Assembly
34	738-04420	Spacer, Shoulder, 1.375 X .380 X .183
35	747-04139	Rod, Brake, Hydro
36	747-04957A	Rod, Transmission, Footpedal Bypass
37	747-04979	Rod, Control, Hydro

Ref.	Part Number	Description
38	747-04991	Rod, Hydro Bypass
39	750-04456	Spacer, .260 X .372 X 1.420 LG
40	954-04207	Belt, V Type, Poly
41	756-04224	Pulley, Idler, Flat 2.75 OD
42	756-04308	Pulley, Input, 4.13 DIA
43	756-04325	Pulley, Idler, V-Type x 3.06
44	783-06027B	Bracket, Idler, Center Double
45	783-06133	Bracket, Mount, Hydro
46	783-06260	Bracket, Support, Belt Disengage
47	783-1019B	Switch Actuator Bracket
48	710-0604A	Taptite Screw, 5/16-18:0.625
49	711-05068A	Clevis Pin, 5/16 x 3.985
50	712-04065	Flangelock Nut, 3/8-16
51	714-04040	Bow-Tie Cotter Pin
52	719-0584B	Control Pedal
53	726-0214	Push Cap
54	732-04587	Extension Spring, .63 DIA x 4.95 LG
55	735-04136	Brake Pedal Pad
56	738-0430	Scr, Shldr, .50 x .685 3/8-16
57	938-0380	Shoulder Bolt, .500 x .270:3/8-16
58	741-0495	Flange Bearing, .630 ID x .695 OD x .60
59	748-04203	Cruise Latch
60	783-05914	Pedal Support Bracket
61	783-05940	Pedal Support Bracket, 5/8
62	783-06103A	Brake Pedal Bracket
63	731-2290A	Hub Cap
64	736-0430	Washer, Flat, .350 x 1.59 x .062
65	634-0104-0911	Wheel Assembly
66	710-05339	Screw, 5/16-24 x .750
67	634-04369-0662	Rim Assembly, Plastic Bead, 46"
68	934-0255	Tubeless Air Valve
69	734-1730-0901	Tire, 20 x 8 x 8
70	941-0490	Axle Hub
71	936-0344	Washer, Flat, .385 x 1.0 x .030
72	747-05444A	Belt Keeper Rod
73	710-1026	Screw, Self Tapping, 1/4-20 x 1.75


42" Deck



Ref.	Part Number	Description
1	918-04822A	Spindle Ass'y, Pulley, 6.3 Dia
2	683-0254B	Bracket Ass'y, Deck, Hanger LH
3	983-04511	Brake Ass'y, Deck, 42/46
4	983-04525	Brake Ass'y, Deck, 46"
5	983-04572A	Deck Ass'y, Offset, 42" W/O wheel
6	710-04484	Screw, Self-tapping, 5/16-18, .750
7	710-3005	Hex Screw, 3/8-16, 1.25, Gr5, Std
8	710-0528	Hex Screw, 5/16-18, 1.25, Gr5, Std
9	710-0599	Screw, Self-tapping, 1/4-20, 0.500
10	936-3039	Flat Washer, .406 x 1.500 x .105
11	710-0642	Screw, Self-tapping, 1/4-20, .750
12	710-3144	Hex Screw, 3/8-16, 2.00, Gr5, Std
13	710-3178	Bolt, Carriage, 3/8-16, 0.75, Gr1
14	712-0229	Nut, Push, 3/8
15	712-04063	Nut, Flange Lock, 5/16-18, Grf
16	712-04065	Nut, Flange Lock, 3/8-16, Grf
17	712-0417A	Nut, Flange, 5/8-18
18	712-04243	Nut, Lock, 1/2-13
19	731-07487	Deck Wash Nozzle
20	753-04070	Lynch Pin, .1875
21	783-06074A	Chute Bracket
22	917-04074	Gear, Deck, Adjustment
23	932-0384	Spring, Extension, .62 Dia x 6.12
24	783-07236	Pulley Cap
25	732-04840	Spring, Torsion, .992 ID X 1.17 OD
26	734-04155	Wheel, Deck, 5.0 Dia Ball
27	936-0119	Washer, Lock, 5/16, Regular Duty
28	941-0919A	Bearing, Ball, .787id x 1.85 Odx.551
29	936-0344	Washer, Flat, .385 X 1.0 X .030
30	710-0376	Hex Cap Screw, 5/16-18 x 1.00
31	720-05010	Cap, .290 x .500

Ref.	Part Number	Description
32	736-0262	Washer, Flat, .385 x .870 x .092
33	750-04936	Spacer, .792 x 1.060 x 1.860
34	783-06643	Bracket, Support, Stationary Idler
35	736-0317	Bell Washer, .63 X 1.25 X .18
36	738-04162C	Spacer, Shoulder, .8840 x .190
37	748-04272	Shoulder Spacer
38	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
39	942-04308	Blade, Cut, 21.23" 2-In-1, Econ
40	747-05323	Rod, Keepr, Belt 42 Idler
41	747-04944B	Deck Lift Rod
42	747-05105B	Rod, Control, Brake 42"
43	631-04288	Chut Assembly, 42" Deck
44	783-06424A	Deck Belt Cover, 42
45	936-0351	Washer, Flat, .760 ldx1.50 OD
46	738-1186A	Shift, Spindle, 6.11.
47	954-04060B	Belt, V Type, A Sec X 96.5
48	756-04129B	Pulley, Idler, 4.25"Dia
49	711-04847B	Pin, Hinge, Dia .3125 x 7.96
50	956-1227	Pulley, Deck, 6.3 Dia
51	732-04372	Spring, Torsion, .44 I.D. X 2.0
52	783-05946	Pivot idler Bracket, 46
53	783-06243	Bracket, Cable, Deck Engage
54	783-06368A	Bracket, Guard, Belt, 4.25 Pulley
55	921-04041	Water Nozzle Adapter
56	738-04278	Shoulder Screw, 1/4-20 x 0.50
57	914-0470	Cotter Pin, 1/8 X 1.25
58	732-04652	Comp. Spring, .535 OD X 1.751 LG
59	936-0179	Flat Washer, .531 X 1.25 X .100
60	747-1116	Deck Release Handle Rod
61	783-04740	Deck Engage Cable Bracket
62	783-06632	Deck Stop


46" Deck



Ref.	Part Number	Description
1	918-04865A	Spindle Ass'y, Pulley, 6.93 Dia
2	683-0254B	Bracket Ass'y, Deck, Hanger LH
3	983-04511	Brake Ass'y, Deck
4	983-04525	Brake Ass'y, Deck
5	983-04578B	Deck Ass'y, Offset, 46" 2W
6	710-04484	Screw, Self-tapping, 5/16-18, .750,
7	710-0514	Hex Screw, 3/8-16, 1.00
8	710-0528	Hex Screw, 5/16-18, 1.25
9	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
10	783-07236	Pulley Cap
11	710-0642	Screw, Self-tapping, 1/4-20, .75,
12	710-1003	Screw, #10-16:.625
13	710-3144	Hex Screw, 3/8-16, 2.00
14	710-3178	Bolt, Carriage, 3/8-16, 0.75
15	712-0229	Nut, Push, 3/8
16	712-04063	Nut, Flange Lock, 5/16-18
17	712-04065	Nut, Flange Lock, 3/8-16
18	712-0417A	Nut, Flange, 5/8-18
19	712-04243	Nut, Lock, 1/2-13
20	710-0376	Hex Cap Screw, 5/16-18 x 1.00
21	753-04070	Pin, Lynch, .1875
22	714-04040	Bow-Tie Cotter Pin, 72
23	917-04074	Gear, Deck, Adjustment
24	731-06496	Belt Cover
25	932-0384	Spring, Extension, .62 Dia x 6.12
26	732-04652	Spring, Comp, .535 OD x 1.751
27	732-04840	Spring, Torsion, .992 I.D x 1.17 O.D
28	734-04155	Wheel, Deck, 5.0 Dia Ball
29	936-0119	Washer, Lock, 5/16, Regular Duty
30	921-04041	Water Nozzle Adaptor
31	936-0179	Washer, Flat, .531 x 1.25 x .100


Ref.	Part Number	Description
32	720-05010	Cap, .290 x .500
33	941-0919A	Ball Bearing, .787 ID x 1.85 OD x .551
34	736-0262	Washer, Flat, .385 x .870 x .092
35	736-0317	Washer, Bell, .63 x 1.25 x .18
36	936-0344	Washer, Flat, .385 x 1.0 x .030
37	748-04272	Spacer, Shoulder, .50 x .145
38	750-04936	Spacer, .792 x 1.060 x 1.860
39	738-04162C	Spacer, Shoulder, .8840 x .190
40	711-04847B	Hinge Pin
41	938-3056	Bolt, Shoulder, .496 x 2.50, 3/8-16
42	942-04290	Blade
43	747-05323	Rod, Keeper, Belt
44	747-04944B	Rod, Lift, Deck, Frt, 13.7
45	747-05011	Rod, Keeper, Belt
46	747-05052A	Rod, Control, Brake
47	756-04356	Pulley, Deck, 6.93 Dia
48	747-1116	Rod, Handle, Deck Release
49	731-07487	Deck Wash Nozzle
50	738-04278	Shoulder Screw, 1/4-20 x 0.50
51	751B221535	Clamp, Casing
52	954-04219	Belt, V-Type
53	756-04129B	Pulley, Idler, 4.25"Dia
54	937-3000	Fitting, 3/16, Lnc#70, Drive Lube
55	738-1186A	Shift, Spindle, 6.11.
56	783-05946	Bracket, Idler, Pivot
57	783-06243	Bracket, Cable, Deck Engage
58	783-06368A	Bracket, Guard, Belt, 4.25 Pulley
59	783-06643	Bracket, Support, Deck Stationary Idler
60	783-06074A	Bracket, Chute
61	631-04288	Chute Ass'y, Deflector
62	732-04372	Torsion Spring, .44 ID x 2.0

Hood and Dash, K Style




Ref.	Part Number	Description
1	931-04663	Dash Assenbly
2	710-0599	Taptite Screw ,1/4-20:0.500
3	710-04484	Taptite Screw ,5/16-18:.750
4	710-0895	Hi-Lo Screw, 1/4-15:0.750
5	710-1017	Screw, 1/4-14:0.625
6	710-1611B	Taptite Screw ,5/16-18:0.750
7	714-04040	Bow Tie Cotter Pin
8	731-06639	Dash Lever
9	731-06642	Cruise Cover
10	931-06212	Plenum
11	735-0271A	Bumper
12	747-05008	Control Rod
13	747-1196	Lever
14	783-04285F	RH Support Plate
15	783-04323F	LH Support Plate
16	710-1652	Tap Screw, 1/4-20, 0.625
17	683-04441A	Hood Assembly
18	710-05108	Screw, 1/4 DIA:.750
19	731-06095	LH Lens
20	731-06096	RH Lens
21	738-04091A	Shoulder Screw, .43 x .29
22	747-04161	LH Tank Support Rod
23	747-04946	RH Tank Support Rod
24	951-04309	Fuel Tank
25	951-12182	Fuel Cap
26	925-0963	Lamp
27	925-1649	Lamp Socket
28	731-1999	Choke Plug
29	946-04542	Throttle/Choke Cable, 46.5"
—	746-04364	Throttle/Choke Cable, 25"
30	925-04227B	Key Switch Module
31	925-04036C	Hour Meter
32	712-04064	Flangelock Nut, 1/4-20
33	625-05002	Key, Assembly
34	631-04272	Grill
35	710-0751	Hex Screw, 1/4-20:.620
—	726-04096	Choke Hole Plug (Not Shown)

Engine Accessories, Single



Ref.	Part Number	Description
1	683-04549	Muffler Shield Assembly
2	710-0227	Screw, Indented Washer, #8-18:0.500
3	710-04683A	Taptite Screw, 3/8-16:1.000
4	710-0642	Taptite Screw, 1/4-20:0.750, Briggs
5	710-1314A	Socket Head Screw, 5/16-18:0.750
6	BS-692236	Gasket, Exhaust, Briggs
7	712-0271	Sems Nut, 1/4-20
8	751-3141-14	Extension Hose, Oil Drain
9	725-0157	Cable Tie, 3/16 x .05 x 7.4
10	726-0205	Hose Clamp, .490 DIA.
11	751-11053A	Long Muffler Deflector
12	751-10448D	Muffler, Briggs
13	951-10517A	Oil Drain
14	751-10349	Fuel Hose



Ref.	Part Number	Description
1	683-04549	Shield Ass'y, Muffler
2	710-0227	Screw, Ab, #8-18, 0.500,
3	710-04683A	Screw, Self-tapping, 3/8-16, 1.000,
4	710-0599	Screw, Self-tapping, 1/4-20, 0.500,
5	710-1314A	Screw, Socket Head, 5/16-18, .750
6	712-0271	Nut, Sems, 1/4-20
7	751-3141-14	Hose, Extension, Oil Drain
8	721-0460	Gasket, Exhaust, Briggs
9	725-0157	Cable, Tie, 3/16 x .05 x 7.4
10	726-0205	Clamp, Hose, .490 Dia.
11	951-10517A	Drain, Oil
12	751-10542A	Muffler, Briggs Twin
13	751-12089-28	Hose, Vent
14	751-10349-28	Hose, Fuel, Low Permeation, 1/4
15	751-11053A	Deflector, Muffler, Long



To order replacement parts or locate your nearest service dealer call a Customer Support at (800) 800-7310.
or visit www.mtdproducts.com to find the nearest authorized dealer in your area.

MTD LLC, P.O. BOX 361131 CLEVELAND, OHIO 44136-0019
