


REPLACEMENT PARTS - MODELS RM4618 AND RM4620

46CC CHAIN SAWS

PPNs 41AY469S883, 41BY469S883, 41AY462S883 and 41BY462S883




Item	Part No.	Description
1	753-08106	Muffler Assembly
2	753-08217	46cc Short Block Assembly
3	794-00126	Spark Plug
4	753-08129	Air Filter Cover Assembly

Item	Part No.	Description
5	753-08134	Air Filter
6	753-08135	Cylinder Cover Assembly (with Plate and Screws (5))
7	753-08137	Carburetor Assembly

REPLACEMENT PARTS - MODELS RM4618 AND RM4620

46CC CHAIN SAWS

PPNs 41AY469S883, 41BY469S883, 41AY462S883 and 41BY462S883



Item	Part No.	Description	Item	Part No.	Description
1	753-06265	Saw Chain 18" (for RM4618)	11	753-08221	Choke Lever Assembly
	753-08102	Saw Chain 20" (for RM4620)	12	753-08223	Stop Switch Assembly
2	753-06264	Guide Bar 18" (for RM4618)	13	753-08132	Throttle Rod
	753-08101	Guide Bar 20" (for RM4620)	14	753-08123	Fuel Filter
3	753-08105	Guide Bar Nuts (2)	15	753-08133	Fuel Cap Assembly
4	753-08219	Sprocket	16	753-08222	Oil Cap Assembly
5	753-08220	Clutch Drum Assembly	17	753-08138	Ignition Module Assembly (with Screws (2))
6	753-08145	Clutch Assembly	18	753-08131	Flywheel Assembly
7	753-08130	Chainsaw Handle Assembly (with Screws (4))	19	753-08310	Starter Housing Assembly
8	753-08128	Spike Plate (with Screws (2))	20	753-08143	Chainsaw Brake Assembly
9	753-08142	Fuel Tank Assembly			
10	753-08127	Primer Bulb			