


REPLACEMENT PARTS - MODEL TB304S

4-CYCLE TRIMMER

PPN 41AD304S766



Item	Part No.	Description	Item	Part No.	Description
1	753-09884	Engine Cover Assembly (includes 2 & 3)	22	753-06948	Carburetor Gasket
2	710-04194	Cover Screw	23	751-16046-4	Carburetor w/Primer
3	791-181003	Screw	24	791-181751	Air Cleaner O-Ring
4	753-05901	Rocker Cover	25	841-034673S	Air Cleaner Cover Assembly (incl. 26)
5	753-05902	Rocker Cover O-Ring	26	753-05254	Air Filter
6	753-05910	Cylinder O-Ring	27	710-04517	Screw
7	753-10205	Breather Hose	28	753-06797	Fuel Tank Assembly (includes 29)
8	753-05408	Oil Plug (includes 9)	29	753-1229	Fuel Cap
9	791-182290	Oil Plug O-Ring	30	753-05259	Fuel Tank Pads
10	753-06259	Crankcase Cover	31	753-10204	Starter Housing Assembly (incl. 3 & 38)
11	753-05238	Crankcase Cover O-ring	32	753-06281	Clutch Assembly
12	753-06221	Flywheel Assembly	33	753-09887	Clutch Cover (includes 2)
13	753-05264	Lead Wires	34	791-182519	Anti-Rotation Screw
14	753-09885	Module Assembly	35	753-04003	Clamp Screw
15	753-05245	Muffler Assembly (includes 16 & 17)	36	712-0161	Nut
16	753-05244	Muffler Gasket	37	841-021441S	Shortblock Assem. (incl. 3-9, 11, 18 & 39)
17	710-04809	Muffler Screw	38	750-04434	Spacer
18	794-00082	Spark Plug	39	791-181025	Rocker Cover Screw
19	753-05247	Insulator Gasket	40	753-06949	Heat Shield
20	712-04099	Nut	41	791-181709	Gasket
21	841-020801S	Insulator			

REPLACEMENT PARTS - MODEL TB304S

4-CYCLE TRIMMER

PPN 41AD304S766

Item	Part No.	Description
42	753-09888	Throttle Housing Assem. (incl. 43 - 47)
43	731-08433C-10	Throttle Trigger Lock-Out
44	791-182405	Trigger Switch Assembly
45	753-05007	Throttle Trigger Spring
46	731-04970B-10	Throttle Trigger
47	732-06186	Shoulder Support Clip
48	746P04758	Throttle Cable Assembly
49	753-06676	Upper Shaft Housing Assembly
50	731-08926	Hanger
51	753-06039	Handle (includes 52)
52	753-06040	Handle Bolt
53	753-1190	Split Boom Coupler (includes 54)
54	791-182057	Anti-Rotation Screw
55	753-08196	Lower Shaft Housing Assembly
56	753-08192	Lower Flexible Drive Shaft
57	753-08180	Gearbox Assembly (includes 58 - 60)
58	791-182519	Anti-rotation Screw
59	791-182195	Gearbox Mounting Hardware
60	748-05052	Cutting Head Driver
61	841-032093S	Shield Assembly (includes 62 & 63)
62	753-04282	Shield Mounting Hardware
63	753-08355	Blade Assembly
64	841-032392S	Cutting Head Assembly (includes 65)
65	753-08563	Bump Knob

